

Illustrated Parts List

Brake Assembly – 10” External Single Cylinder, Four Piston

30-100

Metallic Lining




FIG.	PART NO.	DESCRIPTION	30-100
	091-08000	Cylinder Assembly	1
1	061-05400	Cylinder	1
	092-03400	Piston Assembly	4
2	062-03200	Piston	4
3	082-02000	Friction Spring	4
4	088-00100	Insulator	4
5	101-23200	O-Ring (MS28775-132)	4
	073-04000	Pressure Plate Assembly	1
6	063-02600	Pressure Plate	1
8	177-01600	Pin-Lining	8
9	066-06600	Lining	4
	074-03400	Back Plate Assembly	4
7	064-02700	Back Plate	4
8	177-01600	Pin-Lining	8
9	066-06600	Lining	4
10	068-03100	Shim-Insulator	1
11	069-00400	Anchor Bolt	2
12	095-10200	Washer (AN960-416L)	10
13	094-10300	Nut (MS21044-N4)	2
14	103-11800	Bolt	8
15	183-00100	Cap-Bleeder	1
16	079-00300	Screw-Bleeder	1
17	081-00200	Seat-Bleeder	1
18	101-00700	O-Ring (MS28775-012)	1
19	075-01902	Torque Plate Assembly	1