


3050

Tube-Type



NOTES:

(1) Brake drum assembly must be purchased separately.

(2) 199-2 Grease Seal Kit converts wheel to 3050A .

FIG.	PART NO.	DESCRIPTION	3050 (2)
1	161-01600	Inner Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
3	169-00201 (1)	Brake Drum Assembly	1
4	162-00600	Outer Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
5	103-11000	Bolt (AN4-36A)	3
6	094-10300	Nut (MS21044-N4)	3
7	095-10400	Washer (AN960-416)	3
8	157-00200	Dust Shield	1
10	153-00300	Ring-Grease Seal	1
11	154-00500	Felt-Grease Seal	1
12	158-01000	Hub Cap	1
13	102-25100	Screw (AN526-1024-8)	1
14	102-05100 (2)	Screw (AN500-8-8)	3
15	095-15400	Lock-Washer (AN936A10)	1
16	095-15100 (2)	Lock-Washer (MS35333-38)	3
17	214-00200	Cone-Bearing	2
18	067-00300	Spacer-Inner Shoulder	1