

38501

Tube-Type




FIG.	PART NO.	DESCRIPTION	38501
1	161-00800	Inner Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
3	162-00600	Outer Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
4	103-11000	Bolt (AN4-36A)	3
5	094-10300	Nut (MS21044-N4)	3
6	095-10400	Washer (AN960-416)	6
7	153-00500	Ring-Grease Seal	4
9A	154-00400	Felt-Grease Seal-Inner Wheel Half	1
9B	154-00500	Felt-Grease Seal-Outer Wheel Half	1
11	102-05100	Screw (AN500-8-8)	6
12	095-15300	Washer-Lock (AN936A8)	6
14	214-00200	Cone-Bearing	2