

40-106A

Tube-Type




FIG.	PART NO.	DESCRIPTION	40-106A (1)
1	161-07200	Inner Wheel Half Assy.	1
2	214-02900	Cup-Bearing	1
3	162-06701	Outer Wheel Half Assy.	1
2	214-02900	Cup-Bearing	1
4	067-03900	Spacer	1
6	164-03906	Brake Disc	1
7	103-20400	Bolt (AN5-35A)	9
8	095-10500	Washer (AN960-516)	18
9	094-10400	Nut (MS21044-N5)	9
10	153-01900	Ring-Grease Seal	2
11	154-02600	Felt-Grease Seal	1
12	155-04400	Snap Ring	2
13	214-02800	Cone-Bearing	2
14	158-01300	Hub Cap	1