

40-129

Tube-Type




FIG.	PART NO.	DESCRIPTION	40-129
1	161-05700	Inner Wheel Half Assembly	1
2	214-01300	Cup-Bearing	1
3	162-05400	Outer Wheel Half Assembly	1
4	214-00900	Cup-Bearing	1
5	067-00600	Spacer	1
6	164-05606	Brake Disc	1
7	103-11300	Bolt (AN4-40A)	9
8	095-10400	Washer (AN960-416)	9
9	094-10300	Nut (MS21044-N4)	9
10	153-01600	Ring-Grease Seal	2
11	154-01600	Felt-Grease Seal	1
12	155-00100	Snap Ring	1
13	155-00600	Snap Ring	1
14	214-01000	Cone-Bearing	1
15	214-01400	Cone-Bearing	1
16	158-00800	Hub Cap	1