


40-41

Tube-Type



NOTES:

* Not illustrate

FIG.	PART NO.	DESCRIPTION	40-41
1	161-03000	Inner Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
3	162-02700	Outer Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
4	164-00300	Brake Disc	1
5	103-20400	Bolt (AN5-35A)	3
6	095-10500	Washer (AN960-516)	3
7	094-10400	Nut (MS21044-N5)	3
8	214-00200	Cone-Bearing	2
9	153-00300	Ring-Grease Seal	1
9A	153-00900	Ring-Grease Seal	2
10	153-01500	Ring-Grease Seal	1
11	154-00800	Felt-Grease Seal	1
12	154-01300	Felt-Grease Seal	1
13	155-00100	Snap Ring	2
14	067-03800	Spacer-Axle	1
*	157-00900	Dust Shield	1
*	095-15100	Washer (MS35333-38)	3
*	102-00600	Screw	3