

40-98

Tube-Type




FIG.	PART NO.	DESCRIPTION	40-98
1	161-02300	Inner Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
3	162-02100	Outer Wheel Half Assembly	1
2	214-00100	Cup-Bearing	1
4	103-20400	Bolt (AN5-35A)	6
5	095-10500	Washer (AN960-516)	6
6	094-10400	Nut (MS21044-N5)	6
7	214-00200	Cone-Bearing	2
8	153-00900	Ring-Grease Seal	2
	153-00300	Ring-Grease Seal	1
9	153-01500	Ring-Grease Seal	1
10A	154-01400	Felt-Grease Seal	1
11	154-01300	Felt-Grease Seal	1
12	155-00100	Snap-Ring	2
13	164-02706	Brake Disc	1